

Operating Instructions Taper Cleaner device



Helmut Diebold GmbH & Co. KG • An der Sägmühle 4 • 72417 Jungingen
Telephone ++49 / 7477 / 871-0 • Fax ++49 / 7477 / 871-30

1 Setup and using instruction

Connect the power supply, 100-240 V primary, 24 V secondary, to the drive unit. To release, pull back the socket sleeve (safety coupling).

Place the cleaning unit on the drive unit. Make sure to align the holes to the two position pins.

For stubborn contamination, we recommend spraying the tapet with a detergent, for example WD40/MOTOREX Power Clean or any similar detergent.

Place the tool in the cleaning unit

Fasten the tool tight, using the turning handle.

Depending on the level of contamination, set the run time to 1-5 minutes, using the rotary knob.

Press the rotary knob and the device starts the cleaning process.

The cleaning process can be finished by pressing the rotary knob again at any time.

Remove the tool and wipe with a soft cloth.

2 Spare brushes

	Spare brushes	
76.542.063	HSK63	on stock
76.542.100	HSK100	on stock
76.542.130	SK30	on stock
76.542.140	SK40	on stock
76.542.150	SK50	on stock
76.542.C6	PSC C6	on stock